


**Conexiones de Latón con Barbas para Manguera**

**Espiga Macho Rosca BSPT**

D.I. Manguera	Rosca BSPT	Latón # de Parte
1/4"	1/8"	1020402BSPT
	1/4"	1020404BSPT
3/8"	1/4"	1020604BSPT
	3/8"	1020606BSPT
	1/2"	1020608BSPT
1/2"	3/8"	1020806BSPT
	1/2"	1020808BSPT
3/4"	3/4"	1021212BSPT
1"	1"	1021616BSPT



**Macho NPTF Giratorio x Barbas para Manguera**

D.I. Manguera	Macho NPTF	Latón # de Parte
1/4"	1/8"	1030402C
	1/4"	1030404C
	3/8"	1030406C
5/16"	1/4"	1030504C
3/8"	1/4"	1030604C
	3/8"	1030606C
1/2"	3/8"	1030806C
	1/2"	1030808C
5/8"	1/2"	1031008C
3/4"	1/4"	1031204C
	1/2"	1031208C
	3/4"	1031212C
1"	1-11-1/2"	1031616C



**H**

NOTA: La conexión giratoria es para conveniencia solamente, no utilice como giratoria constante. Presión de operación a **80 PSI**.

**Macho NPTF x Espiga para Abrazadera**

D.I. Manguera	Macho NPTF	Latón # de Parte
1/4"	1/8"	268B0402
	1/4"	268B0404
5/16"	1/8"	268B0502
	1/4"	268B0504
3/8"	1/8"	268B0602
	1/4"	268B0604
	3/8"	268B0606
1/2"	3/8"	268B0806
	1/2"	268B0808
5/8"	1/2"	268B1008
3/4"	1/2"	268B1208
	3/4"	268B1212

