

Serie-HT Coples Hidráulicos

Serie-HT Cople Intercambio ISO16028 Cara Plana "Flushface" (Rosca Macho)

Medida	Detalle			Medida		D.E. Máximo		Hex pulg.
	# Parte	Roscas	Material	pulg.	mm.	pulg.	mm.	
3/8"	3HTM3	3/8" - 18 NPTF	Acero	2.88	73.2	1.24	31.5	1-1/8"
	3HTM4	1/2" - 14 NPTF	Acero	2.97	75.4	1.24	31.5	1-1/8"
1/2"	4HTM4	1/2" - 14 NPTF	Acero	3.42	86.9	1.54	39.1	1-5/16"



Serie-HT Niple Intercambio ISO16028 Cara Plana "Flushface" (Rosca Macho)

Medida	Detalle			Medida		D.E. Máximo		Hex pulg.
	# Parte	Roscas	Material	pulg.	mm.	pulg.	mm.	
3/8"	HT3M3	3/8" - 18 NPTF	Acero	2.87	72.9	1.24	31.5	1-1/8"
	HT3M4	1/2" - 14 NPTF	Acero	2.96	75.2	1.24	31.5	1-1/8"
1/2"	HT4M4	1/2" - 14 NPTF	Acero	3.03	77.0	1.44	36.6	1-5/16"



HT4M4

Serie-HT Cople Intercambio ISO16028 Cara Plana "Flushface" (Rosca ORB Macho)

Medida	Detalle			Medida		D.E. Máximo		Hex pulg.
	# Parte	Roscas	Material	pulg.	mm.	pulg.	mm.	
3/8"	3HTOM3	9/16" - 18 ORB	Acero	2.75	69.9	1.24	31.5	1-1/8"
	3HTOM4	3/4" - 16 ORB	Acero	2.75	69.9	1.24	31.5	1-1/8"



Serie-HT Niple Intercambio ISO16028 Cara Plana "Flushface" (Rosca ORB Macho)

Medida	Detalle			Medida.		D.E. Máximo		Hex pulg.
	# Parte	Roscas	Material	pulg.	mm.	pulg.	mm.	
3/8"	HT30M3	9/16" - 18 ORB	Acero	2.73	69.3	1.17	29.7	1-1/8"
	HT30M4	3/4" - 16 ORB	Acero	2.73	69.3	1.17	29.7	1-1/8"



HT30M4

Serie-HT Cople Intercambio ISO16028 Cara Plana "Flushface" (Rosca pasa muros Macho)

Medida	Detalle			Medida		D.E. Máximo		Hex pulg.
	# Parte	Roscas	Material	pulg.	mm.	pulg.	mm.	
1/2"	4HTRB4	13/16"-16 ORFS BH	Acero	4.19	106.4	1.54	39.1	1-5/16"
	4HTJB5	7/8" - 14 JIC BH	Acero	4.38	111.3	1.54	39.1	1-5/16"
	4HTRB5	1" - 14 ORFS BH	Acero	4.37	111.0	1.54	39.1	1-5/16"
	4HTRB6	1-3/16"-12 ORFS BH	Acero	4.40	111.7	1.54	39.1	1-5/16"
	4HTJB6	1-1/16" - 12 JIC BH	Acero	4.55	115.6	1.54	39.1	1-5/16"



4HTJB5



4HTRB5