



Adaptadores Hidráulicos - Rosca NPTF

Serie 5502 - Codo 90° Macho NPTF x Hembra NPTF

| Rosca Macho NPTF | Rosca Hembra NPTF | Acero al Carbón Zincado # de Parte | PSI |
|------------------|-------------------|---------------------------------------|------|
| 1/8"-27 | 1/4"-18 | 5502-2-4 | 5000 |
| 1/8"-27 | 1/8"-27 | 5502-2 | 5000 |
| 1/4"-18 | 1/8"-27 | 5502-4-2 | 5000 |
| 1/4"-18 | 3/8"-18 | 5502-4-6 | 4000 |
| 1/4"-18 | 1/2"-14 | 5502-4-8 | 3000 |
| 1/4"-18 | 1/4"-18 | 5502-4 | 5000 |
| 3/8"-18 | 1/8"-27 | 5502-6-2 | 4000 |
| 3/8"-18 | 1/4"-18 | 5502-6-4 | 4000 |
| 3/8"-18 | 1/2"-14 | 5502-6-8 | 3000 |
| 3/8"-18 | 3/8"-18 | 5502-6 | 4000 |
| 1/2"-14 | 3/8"-18 | 5502-8-6 | 3000 |
| 1/2"-14 | 3/4"-14 | 5502-8-12 | 2500 |
| 1/2"-14 | 1/2"-14 | 5502-8 | 3000 |
| 3/4"-14 | 1/2"-14 | 5502-12-8 | 2500 |
| 3/4"-14 | 1"- 11 1/2 | 5502-12-16 | 2000 |
| 3/4"-14 | 3/4"-14 | 5502-12 | 2500 |
| 1"- 11 1/2 | 3/4"-14 | 5502-16-12 | 2000 |
| 1"- 11 1/2 | 1 1/4" - 11 1/2 | 5502-16-20 | 1150 |
| 1"- 11 1/2 | 1"- 11 1/2 | 5502-16 | 2000 |
| 1 1/4" - 11 1/2 | 1"- 11 1/2 | 5502-20-16 | 1150 |
| 1 1/4" - 11 1/2 | 1 1/4" - 11 1/2 | 5502-20 | 1150 |
| 1 1/2" - 11 1/2 | 1 1/2" - 11 1/2 | 5502-24 | 1000 |
| 2"-11 1/2 | 2"-11 1/2 | 5502-32 | 1000 |
| 1/8"-27 | 1/8"-27 | 5502C-2 | 5000 |
| 1/4"-18 | 1/4"-18 | 5502C-4 | 5000 |
| 3/8"-18 | 3/8"-18 | 5502C-6 | 4000 |
| 1/2"-14 | 1/2"-14 | 5502C-8 | 3000 |
| 3/4"-14 | 3/4"-14 | 5502C-12 | 2250 |
| 1/4"-18 | 1/4"-18 | 5502SW-4-4 | 5000 |
| 3/8"-18 | 3/8"-18 | 5502SW-6-6 | 4000 |
| 1/2"-14 | 1/2"-14 | 5502SW-8-8 | 3000 |
| 3/4"-14 | 3/4"-14 | 5502SW-12-12 | 2250 |



(1) Macho NPTF
(2) Hembra NPTF
+ C=Compacto

* SW = Un extremo giratorio
SAE 140239